



Roland JC120

**Rated Power Output**

**120W**

**Nominal Input Level**

**INPUT jack: -30 dBu (680 k ohm)**

**Speakers**

**30 cm (12 inches) x 2**

**Controls**

**POWER switch**

**[CHANNEL-1]**

**BRI (Bright) switch**

**VOLUME knob**

**TREBLE knob**

**MIDDLE knob**

**BASS knob**

**[CHANNEL-2]**

**BRI (Bright) switch**

**VOLUME knob**

**TREBLE knob**

**MIDDLE knob**

**BASS knob**  
**DISTORTION knob**  
**REVERB knob**  
**SPEED knob**  
**DEPTH knob**  
**VIB/CHORUS switch**

**Indicator**  
**POWER**

**Connectors**

**[CHANNEL-1, CHANNEL-2]**

**INPUT HIGH, LOW jacks: 1/4-inch phone type**

**LINE OUT L/MONO, R jacks: 1/4-inch phone type**

**[CHANNEL-2 EFFECT LOOP]**

**SEND jack: 1/4-inch phone type**

**RETURN L/MONO, R jacks: 1/4-inch phone type**

**LOOP switch SERIES/PARALLEL**

**LEVEL switch +4 dBu/-20 dBu**

**FOOT SWITCH (CHORUS VIBRATO, REVERB, DISTORTION) jacks: 1/4-inch phone type**

**Power Consumption**

**110 W**

**Accessories**

**Owner's manual**

**Options (sold separately)**

**Footswitch (BOSS FS-5L, FS-6, FS-7)**

**SIZE AND WEIGHT( INCL. CASTERS )**

**Width**

**760 mm**

**29-15/16 inches**

**Depth**

**280 mm**

**11-1/16 inches**

**Height**

**622 mm**

**24-1/2 inches**

**Weight**

**28.0 kg**

**61 lbs. 12 oz.**

